



JONA SHIELD

JONA SHIELD INSTALLATION

1. Turn off any floor heating and assure the floor or surface is dry prior to using Jona Shield temporary floor protection. Install with self-adhering side down and easily roll out to fit the desired area you want to protect.
2. Overlap each roll by 4" or 10 cm for ideal protection against spills and moisture. You may want to tape down the Jona Shield seams for assurance against accidental lifting causing spills, trips and other potential accidents.
3. Follow the manufacturers' guidelines for curing times of flooring. It is recommended that Jona Shield is not used prior to 72 hours after the final coat has been applied. Please also assure that the room temperature is set between 10°C - 25°C and room humidity is between 50% - 60%.
4. When finished with Jona Shield you can reuse for future use. Fold up and store in a cool and dry area.

Additional Considerations:

Be sure the covered area does not release any solvent vapours.

Do not use Jona Shield on new porous floors such as stone or earthenware. Should you find any residue from the Jona Shield after it is removed simply wipe the surface down with a towel dampened with lukewarm water and hand soap.

The details of this informational sheet do not represent nor imply a guarantee of certain properties. It is the responsibility of the processor and end user to determine suitability of Jona Shield temporary floor protection for particular applications. Jona Panel Sales Inc. disclaims any liability if the adherent underside remains on the floor.