



**WhisperWalk**

# Advanced Technology Foam Underlayment X-3100 F

Whisper Walk 3100 series underlayment is to be used under click type engineered wood and laminate flooring. It is not suitable under vinyl flooring.

For concrete substrates, or other substrates where moisture intrusion from the substrate is possible, follow these instructions. However, please note the below method provides a seal against moisture. If there is no risk of moisture intrusion the Whisper Walk may be cut to fit the room rather than extending it up on the walls.

1. Acclimate the finish flooring materials according to the floor manufacturer's instructions.
2. Clean the substrate of all debris, paint residue, etc.
3. Lay out the direction of the flooring.
4. Install the first sheet of Whisper Walk in the same direction as the flooring with the film and sealing tape side down. Put the film edge against the wall and pull the film up over the baseboard; secure with painter's tape to keep it out of the way.
5. Extend the foam 2" up the baseboard or wall on each end.
6. Begin laying the floor and install the first few rows.
7. Cut the next sheet of underlayment 4" longer than the room width. Slip the film edge under the previous sheet, peel the protective paper off the sealing tape, and press firmly to adhere the sealing tape to the film.
8. Continue laying the floor and underlayment until reaching the last row. Allow the underlayment to extend up the wall on both ends and along the long edge of the room.
9. After the floor is completely laid, trim the excess foam and film to the surface level of the finish floor.
10. Complete the floor with a quarter round trim peice.



**JONA** PANEL SALES INC.  
PROGRESSIVE & INNOVATIVE GREEN PRODUCTS  
[www.JonaPanels.com](http://www.JonaPanels.com)